

5639 | 5640

LASER[®]

Soldering Iron

Instructions



Safety First. Be Protected.


Guarantee

If this product fails through faulty materials or workmanship, contact our service department direct on: **+44 (0) 1926 818186**. Normal wear and tear are excluded as are consumable items and abuse.



Distributed by The Tool Connection Ltd

Kington Road, Southam, Warwickshire CV47 0DR
T +44 (0) 1926 815000 F +44 (0) 1926 815888
info@toolconnection.co.uk www.toolconnection.co.uk



www.lasertools.co.uk

Instructions

Before use:

- Do not heat up the soldering iron without ensuring the soldering tip is in place
- Check the setscrew is secure which holds the tip in place and the tip is pushed fully into position.

Warm up the Iron

Warm up the soldering iron thoroughly. Make sure that it is fully up to temperature.

Tinning the soldering tip

Before use, the soldering tip must be tinned. "Tinning" is the process of coating the soldering tip with a thin coat of solder. This aids in heat transfer between the tip and the component you are soldering, and also helps the solder to flow.

Thoroughly coat the tip in solder

Any part of the tip left uncovered may tend to collect flux residue and may not conduct heat properly.

Replacement tips available:

5639 - 0589 - Pack of 2

5640 - 0590 - Pack of 2

Precautions

- The soldering iron is only suitable for 230-240v /50Hz
- Always use on a heat proof base or proprietary soldering iron support (not included).
- Always hold the tool by the handle (all metal components will get hot)
- Always protect the cable from contact with the tip
- The cable cannot be replaced if damaged
- When work is finished allow the tip to cool down slowly
- Do not immerse in water
- Tips can be replaced – always do this when the tool is cold and unplugged from the mains power supply